Poly Documentation

Copyright © 2022, Plantronics, Inc. All rights reserved. No part of this document may be reproduced, translated into another language or format, or transmitted in any form or by any means, electronic or mechanical, for any purpose, without the express written permission of Polycom, Inc 6001 America Center Drive

DTMF Tone Parameters

The following table includes the parameters you can use to set up DTMF tones.

Table 1. DTMF Parameters

lable 1. DTMF Parameters		
Parameter	Permitted Values	Restart or Reboot
reg.1.telephony	Allow telephony services for inbound and outbound calls. 1 (default)	No
tone.dtmf.chassis.masking	0 (default) - DTMF tones play through the speakerphone in handsfree mode. 1 - Set to 1 only if tone.dtmf.viaRtp is set to 0. DTMF tones are substituted with non-DTMF pacifier tones when dialing in handsfree mode to prevent tones from broadcasting to surrounding telephony devices or inadvertently transmitted in-band due to local acoustic echo.	Yes
tone.dtmf.level	The level of the high frequency component of the DTMF digit measured in dBm0; the low frequency tone is two dB lower. -15 -33 to 3	Yes
Printed from Poly (http://documents.polycom.com) tone.dtmf.offTime	When a sequence of DTMF tones is played out automatically, specify the length of time in milliseconds the phone pauses between digits. This is also the minimum inter-digit time when	Page 3 Yes

Related Topics

Dual-Tone Multi-Frequency Tones